



F9572L-V Quick Start Guide

Arista Networks

www.arista.com

**F9572L-V Quick Start Guide,
PDOC-00246-01**

Headquarters	Support	Sales
5453 Great America Parkway Santa Clara, CA 95054 USA +1-408-547-5500 www.arista.com	+1-408 547-5502 +1-866 476-0000 support@arista.com	+1-408 547-5501 +1-866 497-0000 sales@arista.com


© Copyright 2022 Arista Networks, Inc. All rights reserved. The information contained herein is subject to change without notice. The trademarks, logos and service marks ("Marks") displayed in this documentation are the property of Arista Networks in the United States and other countries. Use of the Marks are subject to Arista Network Terms of Use Policy, available at <http://www.arista.com/en/terms-of-use>. Use of marks belonging to other parties is for informational purposes only.

Quick Start Guide


54-Port 25G/100G Fiber Ethernet Switch


F9572L-V | F9572-V


1. Unpack the Switch and Check Contents




F9572L-V or
F9572-V


 Rack Mounting Kit—2 front-post brackets, 2 rear-post brackets, 20 screws, and 2 ear-locking screws


 Power Cord (included with AC PSUs only)


 Grounding Wire (included with DC PSUs only)

 Console Cable—RJ-45 to DB-9

 DC Power Connector (included with 48 VDC PSU only)


 Dust Cover Kit—6 for QSFP port and 48 for SFP ports

 Documentation—*Quick Start Guide* (this document) and *Safety and Regulatory Information*


 **Warning:** For a safe and reliable installation, use only the accessories and screws provided with the AS7312-54XS/AS7316-54XS. Use of other accessories and screws could result in damage to the unit. Any damages incurred by using unapproved accessories are not covered by the warranty.

Avertissement: Pour une installation sûre et fiable, utilisez uniquement les accessoires et les vis fournies avec le AS7312-54XS/AS7316-54XS. L'utilisation d'autres accessoires et vis pourrait endommager l'appareil. Les dommages causés par l'utilisation d'accessoires non approuvés ne sont pas couverts par la garantie.


 **Note:** The switch has the Open Network Install Environment (ONIE) software installer pre-loaded on the switch, but no switch software image. Information about compatible switch software can be found at www.edge-core.com.

 **Caution:** The switch includes plug-in power supply (PSU) and fan tray modules that are installed into its chassis. All installed modules must have a matching airflow direction. That is, if the installed power modules have a front-to-back (F2B) airflow direction, all the installed fan tray modules must also have a F2B airflow direction.


Attention: Le commutateur comprend des modules d'alimentation et de bac de ventilateurs installés sur son châssis. Tous les modules installés doivent avoir une direction de circulation d'air correspondante. C'est-à-dire que tous les modules doivent avoir la même direction de circulation d'air: avant vers arrière (F2B), ou arrière vers avant (B2F).

 **Note:** The switch drawings in this document are for illustration only and may not match your particular switch model.

2. Attach the Brackets




- 1 Attach each of the front- and rear-post brackets to the switch using four of the included bracket screws.
- 2 Use an additional two screws to secure each of the rear-post brackets at the mid-point on the sides of the switch.
- 3 Use the screws and cage nuts supplied with the rack to secure the switch in the rack.

 **Caution:** Installing the switch in a rack requires two people. One person should position the switch in the rack, while the other secures it using the rack screws.

Attention: Deux personnes sont nécessaires pour installer un commutateur dans un bâti : La première personne va positionner le commutateur dans le bâti, la seconde va le fixer avec des vis de montage.


装置の吸排気に必要な領域をマニュアル上に規定している。

3. Adjust Rear-Post Bracket Ears



- 1 Lock the position of the rear-post bracket ears using the included position-locking screws. You can also adjust the rear-post bracket ears to fit different rack depths from 56 cm to 75 cm.


4. Ground the Switch



- ① Ensure the rack is properly grounded and in compliance with ETSI ETS 300 253. Verify that there is a good electrical connection to the grounding point on the rack (no paint or isolating surface treatment).
- ② Attach the #14 AWG to the grounding point on the switch rear panel. Then connect the other end of the wire to rack ground.
For details on grounding the switch with a 12 VDC PSU in an Open Rack, refer to the Edgework ORSA-1U Open Rack Tray Set *Installation Guide*.

Caution: The earth connection must not be removed unless all supply connections have been disconnected.
Attention: Le raccordement à la terre ne doit pas être retiré sauf si toutes les connexions d'alimentation ont été débranchées.


5. Connect Power



- ① Install one or two AC or DC PSUs in the switch. The switch supports up to two PSUs that must have the same matching airflow direction as the installed fan tray.
- ② Connect an external AC or DC power source to the PSUs.
- ③ Connect the Open Rack tray connector to the 12 VDC PSU when the switch is installed in an Open Rack.

Caution: Use a UL/IEC/EN 60950-1 certified power supply to connect to a DC converter, and a #14 AWG (for -36 VDC to -72 VDC PSU) or #8 AWG (for 12 VDC PSU) wire to connect to a DC PSU.

Attention: Utilisez une alimentation certifiée UL/IEC/EN 60950-1 pour le connecter à un convertisseur CC et un câble AWG #14 (pour -36 VDC à -72 VDC) ou AWG #8 (pour 12 VDC PSU) pour vous connecter à une alimentation CC.




- ① Positronic PLA03F7000/AA
- ② DC Return
- ③ -36 -- -72 VDC
- ④ Ground

Caution: Use a UL/IEC/EN 60950-1 certified power supply to connect to a DC converter, and a #14 AWG (for 36–72 VDC PSU).

Attention: Utilisez une alimentation certifiée UL/IEC/EN 60950-1 pour le connecter à un convertisseur CC et un câble AWG #14 (pour -36 à -72 VDC) pour vous connecter à une alimentation CC.

6. Verify Switch Operation




- ① Verify basic switch operation by checking the system LEDs. When operating normally, the PSU1/PSU2 and Fan LEDs should all be on green.

7. Perform Initial System Boot

- ① If the network operating system (NOS) installer is located on a network server, first connect the RJ-45 Management (Mgmt) port to the network using 100-ohm Category 5, 5e or better twisted-pair cable. (Not required if the NOS installer is located on attached storage.)
- ② Boot the switch. Wait for the ONIE software to locate and execute the NOS installer, and then wait for the installer to load the NOS software image. Subsequent switch boots will bypass ONIE and directly run the NOS software.

Note: For switches with ONIE software pre-loaded, refer to the network operating system (NOS) installer and NOS documentation for details on software options and set up for ONIE.

8. Connect Network Cables



- ① For the RJ-45 Management port, connect 100-ohm Category 5, 5e or better twisted-pair cable.
- ② Connect DAC cables to the SFP28/QSFP28 slots. Or first install SFP28/QSFP28 transceivers and then connect fiber optic cabling to the transceiver ports.
The following transceivers are supported:
 - 100GBASE-CR4, AOC, SR4, LR4, and PSM4
 - 40GBASE-CR4, SR4, and LR4
 - 25GBASE-CR4, AOC, and SR
 - 10GBASE-CR, SR, and LR
- ③ As connections are made, check the port status LEDs to be sure the links are valid.
For the SFP28 ports:
 - Green — 25 Gbps mode
 - Amber — 10 Gbps mode
 Each QSFP28 port has four LEDs that indicate valid links in the following modes:
 - 1 LED Green — 100 Gbps mode
 - 1 LED Blue — 40 Gbps mode
 - 1-4 LEDs Amber — 25 Gbps breakout mode (four lanes)
 - 1-4 LEDs Purple — 10 Gbps breakout mode (four lanes)

Hardware Specifications

Switch Chassis

Size (WxDxH)	438.4 x 473 x 44 mm (17.26 x 18.62 x 1.73 inches)
Weight	AS7312-54XS: 9.43 kg (20.78 lb), with two installed PSUs AS7316-54XS: 9.6 kg (21.164 lb), with two installed PSUs
Temperature	Operating: 0° C to 45° C (32° F to 123° F) Storage: -40° C to 70° C (-40° F to 158° F)
Humidity	Operating: 5% to 95% (non-condensing)
Power Consumption	AS7312-54XS: 584 W (maximum power consumption) AS7316-54XS: 629 W (maximum power consumption)

AC PSU

Power Rating	100–240 VAC, 50-60 Hz, 650 Watts
AC Input	100–240 VAC, 50-60 Hz, 10–5 A or 8.2-3.5 A or 7.8-3.8 A
DC Output	5 VSB @ 4-2.5 A, 12 VDC @ 54 A-52.9 A

48 VDC PSU

Power Rating	48 VDC, 650 Watts
DC Input	36-72 VDC, 25-11A
DC Output	5 VDC @ 4 A, 12 VDC @ 52.9 A

12 VDC PSU (PSU-12V-750)

DC Input	12 VDC (from Open Rack busbar)
----------	--------------------------------

Regulatory Compliances


Emissions	EN 55032:2015+AC:2016, Class A EN 61000-3-2:2014, Class A EN 61000-3-3:2013 CCC (GB9254-2008 (Class A)) BSMI (CNS13438) FCC Class A VCCI Class A CE Mark
Immunity	EN 55024:2010+A1:2015 IEC 61000-4-2/3/4/5/6/8/11
Safety	UL (CSA 22.2 No 60950-1 & UL60950-1) CB (IEC/EN60950-1) CCC (GB4943.1-2011) BSMI (CNS14336-1)
Taiwan RoHS	CNS15663

快速入门指南

54端口25G/100G 以太网交换机

F9572L-V | F9572-V

1. 打开交换机的包装并检查内装物



F9572L-V 或
F9572-V

前柱支架 x2, 带可调节吊耳的后柱支架 x2, 支架螺丝 x20, 后支架吊耳位置 - 锁定螺丝 x2



电源线 (仅随 AC PSU 附带)



接地线 (仅随 DC PSU 附带)



控制台线 — RJ-45 转 DB-9



DC 电源转接头 (仅随 48 VDC PSU 附带)



QSFP 接口防尘塞 x 6, SFP 接口防尘塞 x 48



文档 — 快速入门指南 (本文档) 以及安全和管制信息



警告: 为了可以更安全的使用与安装机台, 请务必使用 AS7312-54XS/AS7316-54XS 随货附赠的配件, 避免导致设备损坏或其他风险产生。使用未经批准的配件造成的任何损坏, 均不在保修范围内。



注意: 此交换机预装了 Open Network Installer Environment (ONIE) 软件, 但没有预装交换机映像。有关其他交换机相容软件, 请参考 www.edge-core.com 网站说明。




小心: 本交换机的机箱中安装有插入式电源 (PSU) 和风扇架模块。所有后部安装模块都必须具有匹配的气流方向。即, 如果安装的电源模块有从前到后 (F2B) 的气流通过, 则所有安装的风扇架模块也必须有 F2B 气流通过。



注意: 本文档中的交换机图片仅用于举例说明, 不一定与您的交换机实际外观完全一致。

2. 安装交换机




- 1 使用四个随附的支架螺丝将各个前柱和后柱支架安装到交换机。
- 2 使用另外两个螺丝将每个后柱支架固定到交换机侧面上的中间点。
- 3 使用机架随附的螺丝和卡式螺母将交换机固定到支架上。




小心: 将此交换机安装在机架中时需要两个人。一个人将交换机放置在机架中, 同时另一个人用机架螺丝将其固定。
装置の吸排気に必要な領域をマニュアル上に規定している。

3. 调整后柱支架吊耳



- 1 使用随附的定位螺丝固定后柱支架吊耳的位置。此外, 还可以调整后柱支架吊耳以适合不同的机架深度, 范围是 56 cm 到 75 cm。

4. 对交换机实施接地




- 1 请确保对机架正确实施接地, 并确保符合 ETSI ETS 300 253。请确认机架上的接地点的电气导通状态良好 (确保没有油漆或绝缘表面处理)。
- 2 将 14 号的 AWG 接地线连接至交换机背面面板上的接地点上。然后将接地线的另一端连接至机架的接地。关于如何连接 12 VDC PSU 至开放式机架连接器, 请参阅 Edgecore ORSA-1U Open Rack Tray Set 安装手册。




小心: 在断开所有电源连接前, 切勿断开接地。

5. 连接电源



- ① 在交换机上安装 1 个或 2 个 AC 或 DC 电源模块。本交换机可使用最多 2 个 PSU，且 PSU 的气流方向必须与安装的风扇框相同。
- ② 将外部 AC 或 DC 电源连接至模块。
- ③ 交换机安装在开放型机架中时，将机架的托架接口连接到 12 VDC PSU。


小心：使用 UL/IEC/EN60950-1 认证的电源连接 DC converter。使用 #14 AWG（用于 -36 VDC 到 -72 VDC PSU）或 #8 AWG（用于 12 VDC PSU）线连接到 DC PSU。



- ① Positronic PLA03F7000/AA 接口
- ② DC 返回
- ③ -36 - -72 VDC
- ④ 接地

警告：使用 UL/IEC/EN60950-1 认证的电源连接 DC converter。使用 #14 AWG（用于 36 VDC 到 72 VDC PSU）。

6. 确认交换机的运转情况




- ① 透过检查系统 LED，确认交换机的基本运转情况。如运转正常，PSU1/PSU2 和风扇 LED 会亮起绿灯。

7. 执行初次系统启动

- ① 如果网络操作系统 (NOS) 安装程序位于网络服务器中，应首先使用 5、5e 类或以上双绞线将 RJ-45 管理 (Mgmt) 端口连接到网络。注意，RJ-45 Mgmt 管理仅支持 1000 Mbps 模式。（NOS 安装程序位于相连的存储装置中时不需要。）
 - ② 启动交换机。等待 ONIE 软件找到和执行 NOS 安装程序，然后等待安装程序加载 NOS 软件映像。以后交换机启动时将跳过 ONIE 而直接运行 NOS 软件。
- 注意：**有关 ONIE 软件位置选项和设置的详细信息，请参见 NOS 安装程序和 NOS 文档。

8. 连接网线



- ① 对于 RJ-45 管理端口，请连接 100-ohm 类别 5、5e 或以上的双绞线。
- ② 将 DAC 缆线连接至 QSFP28 插槽。也可先安装好 QSFP28 收发器，然后将光纤连接至收发器端口上。可使用以下收发器：
 - 100GBASE-CR4, AOC, SR4, LR4 和 PSM4
 - 40GBASE-CR4, SR4 和 LR4
 - 25GBASE-CR4, AOC 和 SR
 - 10GBASE-CR, SR 和 LR
- ③ 建立连接后，检查端口状态 LED，确保连接正常。
QSFP28 端口：
 - 绿色 — 25 Gbps 模式
 - 橘色 — 10 Gbps 模式建立连接后，检查端口状态 LED，确保连接正常。每个 QSFP28 端口有四个 LED，在以下模式中指示正常连接：
 - 1 LED 绿色 — 100 Gbps 模式
 - 1 LED 蓝色 — 40 Gbps 模式
 - 1-4 LED 橘色 — 25 Gbps 突破模式（四通道）
 - 1-4 LED 紫色 — 10 Gbps 突破模式（四通道）

硬件规格

交换机机箱

尺寸 (宽 x 深 x 高)	438.4 x 473 x 44 mm (17.26 x 18.62 x 1.73 英寸)
重量	AS7312-54XS: 9.43 kg (20.78 磅), 含附带的两个 PSU AS7316-54XS: 9.6 kg (21.164 磅), 含附带的两个 PSU
温度	运转时 : 0°C 至 45°C (32°F 至 123°F) 储存时 : -40°C 至 70°C (-40°F 至 158°F)
湿度	运转时 : 5% 至 95% (非冷凝)
功率消耗	AS7312-54XS: 最大 584 瓦 AS7316-54XS: 最大 629 瓦

AC PSU

额定功率	100 - 240 VAC, 50-60 Hz, 650 瓦
AC 输入	100 - 240 VAC, 50-60 Hz, 10 - 5 A 或 8.2-3.5 A 或 7.8-3.8 A
DC 输出	5 VSB @ 4-2.5 A, 12 VDC @ 54A-52.9 A

48 VDC PSU

额定功率	48 VDC, 650 瓦
DC 输入	36-72 VDC, 25-11 A
DC 输出	5 VDC @ 4 A, 12 VDC @ 52.9 A

12 VDC PSU (PSU-12V-750)

DC 输入	12 VDC (从开放式机架后方的母线取电)
-------	------------------------

法规符合性


排放	EN 55032:2015+AC:2016, A 级 EN 61000-3-2:2014, A 级 EN 61000-3-3:2013 CCC (GB9254-2008), A 级 BSMI (CNS13438) FCC A 级 VCCI A 级 CE 标志
抗扰性	EN 55024:2010+A1:2015 IEC 61000-4-2/3/4/5/6/8/11
安全	UL (CSA 22.2 No 60950-1 & UL60950-1) CB (IEC/EN60950-1) CCC (GB4943.1-2011) BSMI (CNS14336-1)
台湾 RoHS	CNS15663

快速入門指南

54埠25G/100G 乙太網路交換器

AS7312-54XS | AS7316-54XS

1. 拆開交換器包裝並檢查內容物



F9572L-V 或
F9572-V

前柱托架 x2、後柱托架附可調固定片 x2、托架螺絲 x20、後托架固定片位置 - 定位螺絲 x2

電源線 (僅隨附於 AC PSU)

接地線 (僅隨附於 DC PSU)

控制電纜 - RJ45 轉 DB-9

DC 電源轉接頭 (僅隨附於 48 VDC PSU)

QSFP 孔防塵塞 x 6、SFP 孔防塵塞 x 48

文件 - 快速入門指南 (本文件) 及 安全性與法規資訊


警告： 瀧鴉助驟旋娼倭眇乖玳胞娼璽樓勇賈颯冰府乖玳 AS7312-54XS/AS7316-54XS 长讒铸诟眇逆駢賸輻值傳 貼褻佰拏坡慳促鞣勒閉城璘○乖玳帥斷憲傷眇逆駢較悞 眇颯丱拏坡賈喇嚙噴寔仅寇嗒傾○

說明： 交換器有預載之開放網路安裝程式環境 (ONIE) 軟體，但未預載交換器軟體映像檔。有關其他相容交換器軟體請參閱 www.edge-core.com 網站說明。

注意： 交換器包含插入式電源供應器以及風扇托盤模組。所有後部安裝之模組氣流方向，必須一致。意即，如果安裝的電源供應器有從前至後的氣流方向 (F2B)，則所有安裝的風扇托盤模組也必須為前至後的氣流方向 (F2B)。

說明： 本文件使用的交換器圖片僅供舉例說明，不一定與您的交換器外觀完全一致。


2. 安裝交換器



- 1 利用四個所附之托架螺絲，將前柱和後柱托架安裝在交換器上。
- 2 額外使用兩個螺絲，將後柱托架各別固定在交換器側邊中間處。
- 3 使用隨機櫃提供的螺絲及籠罩螺帽，將交換器固定在機櫃上。

注意： 需要兩個人，將交換器裝到機櫃上。一人負責固定交換器在機櫃上之位置，另一人負責用機櫃螺絲固定。裝置的吸排氣に必要な領域をマニュアル上に規定している。

3. 調整後柱托架固定片




- 1 利用所附的定位螺絲，鎖緊後柱托架固定片位置。亦可調整後柱托架固定片，以安裝在深度為 56 cm 至 75 cm 不等之機櫃上。


4. 對交換器實施接地




- 1 請確保對機架正確實施接地，並確保符合 ETSI ETS 300 253。請確認機架上的接地點的電氣導通狀態良好（確保沒有油漆或絕緣表面處理）。
- 2 將 14 號 AWG 接地線連接至交換器背面板上的接地點上。然後將接地線的另一端連接至機架的接地。關於如何連接 12 VDC PSUs 至開放式機架連接器，請參閱 Edgecore ORSA-1U Open Rack Tray Set 安裝手冊。


 注意：在斷開所有電源連接前，切勿斷開接地。

5. 連接電源



- 1 在交換器上安裝 1 個或 2 個 AC 或 DC 電源模組。本交換器可使用最多 2 個 PSU，且 PSU 的氣流方向必須與安裝的風扇框相同。
- 2 將外部 AC 或 DC 電源連接至模組。
- 3 將交換器裝入開放式機櫃後，將開放式機櫃托盤接頭連接至 12 VDC PSU。


 注意：在 DC Converter 的前端必須使用 UL/IEC/EN 60950-1 認證的電源供應器 連接 DC PSU。使用 #14 AWG 線（適用於 -36 VDC 至 -72 VDC PSU）或 #8 AWG 線（適用於 12 VDC PSU）連接至 DC PSU。



- 1 Positronic PLA03F7000/AA 接頭
- 2 DC 回流
- 3 -36 -- -72 VDC
- 4 接地


 殿价螺噴 DC Converter 咻儂秆府嵩乖琨 UL/IEC/EN 60950-1 檻訓咻闌涅恣悠惚 軛扼 DC PSU O乖琨 #14 AWG 梁 (軛玘撓 36 VDC 胸 72 VDC PSU 豈)

6. 確認交換器操作




- 1 透過檢查系統 LED，確認交換器的基本運轉情況。如運轉正常，PSU1/PSU2 和風扇 LED 會亮起綠燈。

7. 執行初次系統啟動

- 1 若網路作業系統（NOS）安裝程式位於網路伺服器，先使用 5-ohm 第 5 類、5e 類或更優之雙絞線電纜，連接 RJ-45 管理（Mgmt）埠至網路。請注意，RJ-45 Mgmt 連接埠僅支援 1000 Mbps 模式。（若 NOS 安裝程式位於所附儲存設備中，則不需要。）
 - 2 啟動交換器。等待 ONIE 軟體找尋並執行 NOS 安裝程式，並等待安裝程式載入 NOS 軟體映像檔。之後交換器啟動時，會跳過 ONIE，直接運行 NOS 軟體。
-  說明：關於詳細軟體選項及 ONIE 設定說明，請參閱網路作業系統（NOS）安裝程式及 NOS 文件。

8. 連接網路線



- 1 對於 RJ-45 管理埠，請連接 100-ohm 類別 5、5e 或以上的雙絞線。
- 2 連接光纖電纜至收發器連接埠。或直接將 DAC 線連接至 QSFP28 插槽。
支援以下收發器：
100GBASE-CR4, AOC, SR4, LR4 和 PSM4
40GBASE-CR4, SR4 和 LR4
25GBASE-CR4, AOC 和 SR
10GBASE-CR, SR 和 LR
- 3 連接完成後，請檢查連接埠狀態 LED，確保連結有效。
QSFP28 連接埠：
綠 - 25 Gbps 模式
橘 - 10 Gbps 突圍模式
連接完成後，請檢查連接埠狀態 LED，確保連結有效。
每個 QSFP28 連接埠有四個 LED，可指出在以下模式中的有效連結：
1 LED 綠 - 100 Gbps 模式
1 LED 藍 - 40 Gbps 模式
1-4 LED 橘 - 25 Gbps 突圍模式 (四道)
1-4 LED 紫 - 10 Gbps 突圍模式 (四道)

硬體規格

韋柯德機架

尺寸 (WxDxH)	438.4 x 473 x 44 mm (17.26 x 18.62 x 1.73 英寸)
重量	AS7312-54XS: 9.43 kg (20.78 磅) · 含兩個安裝 PSU AS7316-54XS: 9.6 kg (21.164 磅) · 含兩個安裝 PSU
溫度	操作: 0°C 至 45°C (32°F 至 123°F) 儲存: -40°C 至 70°C (-40°F 至 158°F)
濕度	操作: 5% 至 95% (無冷凝)
消耗功率	AS7312-54XS: 最大 584 瓦 AS7316-54XS: 最大 629 瓦

AC PSU

額定功率	100–240 VAC, 50-60 Hz, 650 瓦
AC 輸入	100–240 VAC, 50-60 Hz, 10–5 A 或 8.2-3.5 A 或 7.8-3.8 A
DC 輸出	5 VSB @ 4-2.5 A, 12 VDC @ 54A-52.9 A

48 VDC PSU

額定功率	48 VDC, 650 瓦
DC 輸入	36-72 VDC, 25-11 A
DC 輸出	5 VDC @ 4 A, 12 VDC @ 52.9 A

12 VDC PSU (PSU-12V-750)

DC 輸入	12 VDC (從開放式機架後方的母線取電)
-------	------------------------

殲衚稊募卅

排放	EN 55032:2015+AC:2016, Class A EN 61000-3-2:2014, Class A EN 61000-3-3:2013 CCC (GB9254-2008), Class A BSMI (CNS13438) FCC Class A VCCI Class A CE Mark
電磁耐受性	EN 55024:2010+A1:2015 IEC 61000-4-2/3/4/5/6/8/11
安全性	UL (CSA 22.2 No 60950-1 & UL60950-1) CB (IEC/EN60950-1) CCC (GB4943.1-2011) BSMI (CNS14336-1)
台灣 RoHS	CNS15663